CABINET PARTS

For Models: LEQ9558KQ0, LEQ9558KT0
(Designer White) (Biscuit)

29"ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: LEQ9558KQ0, LEQ9558KT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT3397618	Instructions, Installation
	LIT8527926	Use & Care Guide
	LIT8299799	Label, Wiring Diagram

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

	LIT677818	Dryer
2	343641	Screw, 10−16 x 1/2
3	693995	Screw, 8−18 x 3/8
5	3396795	Cover, Block
6	342043	Screw, 10−32 x 3/8
7	3396805	Panel, Rear
10	3406107	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
13	3357011	Screw, 10−16 x 1/2
14	692495	Spring, Door (2)
15	3394083	Clip, Front Panel (2)
16	3392100	Foot, Dryer
	279810	Foot−Optional (Extended Length Package of 2) (Not Included)
17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)
18		Cabinet (Includes Illus. Nos. 5,7,15,41 And 45.)
	3399585	White
	3399595	Biscuit
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21		Panel, Front
	695620	White
	3977244	Biscuit
23	685203	Clip, Felt Pad (3)
24	3389441	Catch, Door Assembly
26	337189	Clip, Hinge (2)
27	694091	Screw, 8−18 x 3/8
28	8066056	Hinge, R.H.
	8066057	Hinge, L.H.
33	696144	Strike, Door
35	695737	Door, Rear
36		Door, Front
	3393549	White
	3977241	Biscuit
37		Handle, Door
	690270	White
	3977242	Biscuit
38	3406129	Seal & Bearing Assembly
39	279393	Terminal Block Kit (For Terminal Block)
40	697776	Screw, 10−32 x 5/8
41	3397659	Block, Terminal
42	238088	Hinge, Top (2)
43	3394332	Idler & Slide Assembly
44	8066065	Belt, Drive
45	348780	Base, Motor
46	3400500	Bolt, 5/16−18 x 3/4
47	3394341	Pulley, 60 Hz.
48	3976707	Motor Assembly 60 Hz.
49	660658	Clamp, Motor
50	3404162	Clamp, Motor (W/Shield)
51	3390731	Seal, Door
52	3393008	Screw, 10−16 x 1/2

TOP AND CONSOLE PARTS

For Models: LEQ9558KQ0, LEQ9558KT0
(Designer White) (Biscuit)



WIRING HARNESS PARTS





FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LEQ9558KQ0, LEQ9558KT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console
2	3401695	Wire, Jumper (Buzzer On/Off)
3	693995	Screw, Hex Head
4		Cap, End (L.H.)
	8271365	White
	8271368	Biscuit
5	3405154	Switch, Finish Guard
6	388326	Screw, Console
7	694419	Buzzer, Mini
8		Cap, End (R.H.)
	8271359	White
	8271362	Biscuit
9	8528330	Switch, Temperature
10	349639	Screen, Lint
11		Cover, Lint Screen
	8283378	White
	8283380	Biscuit
12	3978605	Hinge, R.H.
	3978606	Hinge, L.H.
13	688983	Screw, 8−18 x 5/8
14	3400859	Screw, Grounding
15	3395683	Connector (Motor)
16		Top
	8271390	White
	8271392	Biscuit
17		Knob, Control (3)
	8271339	White
	8271348	Biscuit
18	3394427	Clip−Harness
19	297535	Bumper, Lint Lid
20	3401144	Connector, (PTS Relay)
21	3406725	Timer, 60 Hz.
22	3405152	Switch, End Of Cycle
23		Knob, Push−To−Start
	8271341	White
	8271349	Biscuit
29	3390646	Screw, Mounting (8−18 x 5/16)
30	357213	Nut, Push−In (2)
31	8283282	Harness, Wiring
33	3397269	Connector (Timer)
34	3347243	Connector 6−Circuit
35	94614	Terminal
39	3398094	Switch, Push−To−Start
48		Timer Knob Assembly
	8312687	White
	8271404	Biscuit
50	3936144	Connector
51	3390537	Control, Electronic
52	3391885	Connector, Edge
53	8271418	Bracket, Control
54		Panel, Control
	3977853	White
	3977854	Biscuit
55	343641	Screw, 10−16 x 1/2

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	4392899	Biscuit
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	4392901	Biscuit
	350938	Primer, Gray
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	4392900	Biscuit (Uncut)

BULKHEAD PARTS

For Models: LEQ9558KQ0, LEQ9558KT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LEQ9558KQ0, LEQ9558KT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	487909	Screw, 8−15 x 1/2
3	3388703	Washer−Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8−18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	8318268	Thermostat, Internal−Bias
9	3977393	Thermal, Cut−Off (Hi−Limit Thermostat Illus. No.15 Included)
10	694089	Wheel, Blower (Includes Illus. No. 22)
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10−16 x 1/2
14	3397566	Box, Heater
15	3977767	Thermostat, 221°F (105°C)
16	3977373	Bracket, Drum Light
17	3403585	Element, Heater
18	8066086	Drum Hole Plug
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
20	489463	Screw, 8−18 x 5/8
21	3406839	Dry Rack Assembly
22	3394196	Seal, Blower
23	692989	Bracket, Dry Rack
30	3976479	Pad, Sensor
33	3406124	Bulb
34	3402841	Lens, Drum Light
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8−16
48	3403414	Bulkhead
49	3403634	Socket Assembly
50	692526	Ring, Bearing (2)
51	97787	Screw, 11−16 x 3/4
52	3406130	Seal, Rear Drum
53	695587	Drum Assembly
54	692490	Baffle, Drum (2)
55	3976434	Bracket, Support
56	90296	Clip
57	3403636	Baffle, Drum (1)
58	339956	Seal